



Specialty Tools & Instruments

GENERAL TOOLS & INSTRUMENTS

80 White Street

New York, NY 10013-3567

PHONE (212) 431-6100 FAX (212) 431-6499

TOLL FREE (800) 697-8665

e-mail: sales@generaltools.com

www.generaltools.com

T1872 User's Manual

Specifications subject to change without notice

©2012 GENERAL TOOLS & INSTRUMENTS

NOTICE - WE ARE NOT RESPONSIBLE FOR

TYPOGRAPHICAL ERRORS.

MAN#T1872 9/12/12

BIG DIGIT DUAL TIMER/CLOCK USER'S MANUAL



T1872

*Please read this manual carefully and thoroughly
before using this product.*

PREP INSTRUCTIONS

Remove the plastic film from the display.

Turn the unit over and open the battery compartment by sliding the white plastic cover to the right. Push the magnet in the direction of the arrow.

Insert the supplied “AAA” battery in the battery compartment using the + and – marks inside the compartment as a guide.

The beeper will sound quickly four times. If you have not moved the function switch on the right side of the unit from its factory-set **CLOCK**

position, the display will show a running clock beginning at **12:00:00 AM**. If you have moved the function switch to another position, the display will show **0:00:00**.

4. Replace the battery compartment cover.

TO SET THE CLOCK

1. Make sure the function switch on the right side of the unit is in the **CLOCK** position. Press and hold the large **START/STOP** button on the right side of the front panel. The beeper will sound once and all six display digits will begin blinking once per

Within four seconds, repeatedly press the button on the left side of the front panel until the hour shown matches the current hour. To set a morning or evening hour, continue pressing the button until you pass 11 AM and the indication above the colon is replaced by a indication below the colon.

Within four seconds—press the **MIN** button on the front panel repeatedly until the digits match the current minutes value.

a) *Within four seconds*—press the **SEC** button on the front panel repeatedly until the digits match the current seconds value.

Note: To display time in 24-hour (military) format, press and hold the **CLEAR** button. To return to 12-hour (AM and PM) format, press and hold the **CLEAR** button again.

TO USE THE STOPWATCH (COUNT-UP TIMER)

1. Move the function switch on the right side of the unit to the **COUNT UP** position. The display will show **0:00:00**, with **COUNT UP** above the seconds digits.

press the **START/STOP** button. The beeper will sound and the display will show a stopwatch counting up from 0:00:00.

To pause the count, press the **START/STOP** button. The beeper will sound. To resume the count, press the **START/STOP** button again. The beeper will sound again.

To clear (zero out) the count, press the **CLEAR** button while the count is paused.

1) While the count-up timer is running, pressing the function switch to the **CLOCK** position or **TIMER** position will change the display to the

current time or countdown time, with the flashing words **COUNT UP** above the seconds digits to remind you that the count-up timer (stopwatch) is running.
2) The count will “roll over” to **0:00:00** one second past 23:59:59.

TO USE EITHER COUNTDOWN TIMER

1. Move the function switch on the right side of the unit to the **TIMER 1** or **TIMER 2** position. The display will show **0:00:00**, with **TIMER 1** or **TIMER 2** above the seconds digits.

HR, **MIN** and **SEC** buttons to enter the countdown duration. Press the **MEMORY** button to save this setting. The word **MEMORY** will appear on the display.

Press the **START/STOP** button to begin the countdown. The beeper will sound. Press the **START/STOP** button again to pause the countdown. The beeper will sound again. Press the **START/STOP** button again to resume the countdown. This will cause the beeper to sound again. To clear (zero out) the count, press the **START/STOP** button while the count is paused.

4. The alarm will sound when the countdown reaches 0:00:00. For **TIMER 1**, the alarm is a sequence of four beeps. For **TIMER 2**, the alarm is a sequence of two beeps. When the alarm sounds, the flashing notification **TIME'S UP** will appear in the upper right corner of the display and a new timer will begin counting up from 0:00:00 to indicate how much time has elapsed since the alarm sounded. To cancel the alarm, press the **START/STOP** button. The display will reset to **0:00:00**.
5. To use either timer to time the same period again, move the function switch to the **TIMER 1** or **TIMER 2** position and press the **MEMORY** button.

selected timer's last duration will be recalled and displayed, along with the number of the timer associated with. To change the memorized duration of either countdown timer, enter the new duration using the **HR**, **MIN** and **SEC** buttons and press the **MEMORY** button.

1) **TIMER 1** and **TIMER 2** can run simultaneously. The difference in the sounds of their beeps—four beeps vs. two beeps—comes in handy for timing two events that are part of the same process (such as cooking a meal or brewing beer). Removing the battery clears the clock as well as the memorized durations of **TIMER 1** and **TIMER 2**.

SPECIFICATIONS

- Clock Display: Hours, minutes and seconds in 12 or 24 hour format
- Range of Stopwatch (Count-up timer) and Two Countdown Timers: 23:59:59
- Display Size: 2.25 x 0.8 in. (57 x 20mm)
- Digit Height: 0.75 in. (19mm)
- Dimensions: 2.65 x 2.4 x 0.65 in. (67 x 61 x 17mm)
- Weight: 2.5 oz. (71g)
- Power Source: 1 "AAA" battery (included)

WARRANTY INFORMATION

General Tools & Instruments' (General's) TI872 Big Timer/Clock is warranted to the original purchaser to be free from defects in material and workmanship for a period of one year. Subject to the following restrictions, General will repair or replace this product if, after examination, the company determines it to be defective in material or workmanship.

This warranty does not apply to damages that are determined to be from an attempted repair by unauthorized personnel or misuse, alterations,

normal wear and tear, or accidental damage. The defective unit must be returned to General Tools & Instruments or to a General-authorized service center, freight prepaid and insured.

RETURN FOR REPAIR POLICY

Effort has been made to provide you with a product of superior quality. However, in the event your instrument requires repair, please contact Customer Service to obtain an RGA (Return Goods Authorization) number before forwarding the unit via prepaid freight to the attention of our Service Center at the address:

General Tools & Instruments
80 White Street
New York, NY 10013
212-431-6100

Remember to include a copy of your proof of purchase, your return address, and your phone number and/or e-mail address.